ID4 - Series: C

## SPIR STAR

SPIR STAR 416

## **Applications**

Waterblast: Heat exchanger tube cleaning, surface preparation

(concrete removal, surface cleaning of buildings, paint removal), ultra high-pressure waterjet cutting and hydro

demolition (cutting and demolition of armoured

concrete, pipelines, paper or steel)

**Hydraulics:** Bolt tensioning, pressure test equipment (valves, tooling

and control panels), hydraulic tools (instrumentation packages for gauges, control of service equipment,

hydraulic jacks, hydraulic tools)



Inner Core: Polyoxymethylene (POM)Pressure Support: 6 layers of high-tensile steel wire

Outer Cover: Polyamide (PA)

Color: Blue

**Temperature:**  $-30^{\circ}\text{C to } +70^{\circ}\text{C } [-22^{\circ}\text{F to } 158^{\circ}\text{F}]$ 



Part no.	Thread	Material	Dimensions (mm) A B C 압	Sleeve
Sleeve				
10460102	-	Steel	17,1 48,9	

Part no.	Thread	Material	Nut	Dim A	ensions B	(mm) C	암	Insert
HP fitting								
40460204C	I/4"x28UNF LH	Stainless steel	-	1,8	82	14	-	1-1-1
40460224C	3/8"x24UNF LH	Stainless steel	-	1,8	90	20	-	4
40460234C	9/16"x18UNF LH	Stainless steel	-	1,8	104	24	-	B
Type M fema	le swivel							
20460644C	9/16"x18UNF	Stainless steel	50560605, 50560601	1,8	63	-	22	



4600 I

SPIR STAR®

## ID4 - Series: C

Part no.	Thread	Material	Relief bores	Dim A	ensions B	(mm)	암	Swivel nut
Swivel nut								
50560601	9/16"×18UNF	Steel	l radial	9,2	18	14	22	
50560605	9/16"x18UNF	AISI 316	l radial	9,2	18	14	22	8

Part no.	Thread	Material	Dime A	ensions B	(mm) C	Tylbe cleaning accessories
Stop sleeve						
1.84104601C	-	Steel -	17,1	49	-	50 +5 B
Marking ring						
1.851316.5	-	AISI 316 -	14,5	10	-	- 500 +50

Production related variations of the burst pressure of up to 5 % are possible. Other colors upon request.

The safety factors between the burst pressure and the working pressure as well as the test pressure depend on the operating conditions. For gaseous media the outer cover is to be pinpricked. Regarding the safety factor for gaseous media please contact your local SPIR STAR® assembling center.

The indicated working pressure refers to the hose only. Depending on the used fitting the permitted working pressure of a hose assembly may be less.

\*) Blast-Pro® fittings may only be used for tube cleaning operations inside the tube. They have not been designed for the use outside of tubes.

We reserve our rights for technical changes without notice. Subject to printing errors.

